

PROCEDURES FOR NISSAN X-TRAIL AND QASHQAI PROXIMITY VEHICLES

** Risk of BCM Damage in **Nissan X-Trail and Qashqai 2014–2020 (20 DIGIT SYSTEM)** Vehicles with Proximity Keys

In **2014–2020** Nissan X-Trail and Qashqai models equipped with **proximity keys**, the vehicle may **lock** and experience **BCM failure**, even if all procedures are followed correctly. These situations can be encountered in all other OBD programming devices (including service devices), independent of Zed-FULL or Zed-FULL plus.

This issue is most often caused by **faulty manufacturing in some BCM units**, and unfortunately, there is currently no definitive solution. We strongly recommend that you exercise caution in this regard.

✓ IMPORTANT REMINDER:

Before performing key programming procedures, the following steps must be followed:

1-Ensure the steering column is locked.

- Sit inside the vehicle with all doors closed.
- Turn the ignition ON, then OFF again.
- Open the driver's door and make sure you hear the steering column lock.
- Continue programming after this step.

If the steering lock isn't engaged, you can try the following manual method.

Try turning the steering wheel slightly to the right or left.

You can tell if the steering wheel is mechanically locked by hearing a "click."

If it doesn't lock and the steering wheel turns freely, the lock isn't engaged.

⚠ This procedure is strongly recommended as it is a method that will reduce the risk of BCM locking.

2-If these steps are skipped or if the system does not lock completely, damage to the BCM module may occur. In such cases, the BCM module may need to be replaced, which can be costly.

⚠ HIGH-RISK BCM PART NUMBERS:

Vehicle with the following BCM part numbers are considered high-risk:


- 284B1-3ZP0A
- 284B1-4CB0A
- 284B1-4CB1A
- 284B1-4CB2A
- 284B1-4CB3A
- 284B1-4CB4A
- 284B1-4CB5A
- 284B1-4CE1A




⚠ For vehicles with these part numbers, customers must be informed before proceeding, and the procedures described above must be followed completely.

BCM Location in Vehicle:

- When you are sitting in the driver's seat, the **BCM** is located on the lower left side of the steering wheel, just behind or next to the interior fuse box.
- It's usually located in the **left front footwell**, behind the plastic trim panels.
- It's usually a black or dark gray rectangular box.
- It has one or more connectors (sockets) and a Nissan part number label (for example, **284B1-4CE1A**).










STOCK CODE: NIR111+


Now, let's walk through the coding procedure step by step.
















The **QASHQAI** is used as an example in this application. If the vehicle is an X-TRAIL, you can follow the same steps by entering it from the "X-TRAIL PROX" menu.

















At this stage, all keys to be programmed must be taken into the vehicle and the key programming process must be performed.








⚠ If it does not blink 5 times, repeat the same process.




⚠ Once all keys to be coded have been programmed, **press exit** on the following screen to finish the procedure.























ieakeystore.com





istanbulelektronikanahtar



İstanbul Elektronik Anahtar

Phone: +90 212 485 56 56 WhatsApp: +90 555 872 70 05